

## Program Guide: TV Search Shortcuts

In this tutorial we will show you some Power Tips for finding programs quickly. If you want to brush up on your basic channel browsing skills, review the **Channel Browsing** tutorial.

We will be covering:

- Browse by Time
- Browse by Theme
- Browse by Title

We will be doing all of these from the **Program Guide**, so first press the **GUIDE** button.

Whenever you find the program you want, press the **SELECT** button to tune to it immediately OR if you want to go back to your original program, press the **EXIT** button to clear the screen.

### Browse by Time

#### *Find Programs by Time of Day*

When the **GUIDE** first comes up, you will automatically be browsing by **TIME**. If you ever want to return to this option while you're in the guide, press the **C** button.

#### *Scrolling Through Channels*

1. **Basic:** Press the **UP** or **DOWN** arrow buttons to browse channels one at a time.
2. **Faster:** To scroll faster, press the **PAGE +/-** button to jump one page at a time.

#### *Scrolling Through Time Slots*

1. **Basic:** Press the **LEFT** or **RIGHT** arrow buttons to browse by time slot.
2. **Faster:** Hold down the **RIGHT** arrow button. You will start by moving at normal speed. After a few moments, the channel grid will darken, and you will start moving ahead in **Power Speed** mode. If you go ahead several days, it can take a few moments to load the program information, so you may see the words **No Data** displayed temporarily.
3. To jump back to today's listings, press the **GUIDE** button twice.

## Browse by Theme

### *Find Programs by Theme (Sports, Comedy, Drama, etc.)*

1. Press the **A** button to go to "Browse By" then use the arrow keys to scroll to **THEME** and then press **SELECT**.
2. Categories are listed on the left side of the screen:
  - Main categories, like SPORTS, MOVIES and NEWS are listed in capital letters.
  - Subcategories, like basketball, baseball and football, are listed under each Category.

### *Choose a Theme*

1. **Basic:** Press the **UP** or **DOWN** arrow buttons to scroll through themes one at a time.
2. **Faster:** Press the **PAGE +/-** button to jump a page at a time.
3. Once you find a theme you want, press the **SELECT** button.
4. All available programs are now listed on the right side of the screen. The programs currently playing are listed first, with a small dot next to each of them.
5. To choose a different theme, press the **LEFT** arrow button.

### *Choose a Program*

1. **Basic:** Press the **UP** or **DOWN** arrow buttons to scroll one at a time.
2. **Faster:** Press the **PAGE +/-** button to jump one page at a time.

## Browse by Title

### *Find a Specific Show by Title*

Press the **A** button to "Browse By" and use the arrow keys to scroll to title.

### *Choose a Letter*

1. Press the **UP** or **DOWN** arrow buttons to find the first letter of the show you want.
2. Press the **SELECT** button. An alphabetical list of all the shows that begin with your letter now appear on the right side of the screen. Currently playing shows are marked by a small dot.
3. To search another letter in the alphabet, press the **LEFT** arrow button.

### *Choose a Program*

1. **Basic:** Use the **UP** and **DOWN** arrow buttons to scroll through shows one at a time.
2. **Faster:** Press the **Page +/-** button to jump a page at a time.

**Use your Back button on your browser to return to Answers on Demand Home Page.**