

DVR: Control Live TV

Control Live TV

With DVR, you can use your remote to control live TV - just as if it were a recording.

How does it work?

1. If you're interrupted, or want to take a break - all you have to do is press the **PAUSE** button.



2. When you're ready to go back to your show, press the **PLAY** button to pick up where you left off.



3. To watch in slow motion, press the **PLAY** button twice very quickly.
4. Use the **REWIND** and **FAST-FORWARD** buttons to control the action, just like you would with your VCR. Press these buttons twice to go faster, or three times to go at the fastest speed.



Extra Tips

1. If you come home late, you can still catch your favorite show, as long as your cable box was tuned to the right channel. Your DVR automatically stores up to an hour of the show. Just press the **REWIND** button, and you can play any part of the last hour you've missed.
2. If you are watching live TV, and want to watch an instant replay of something, just press the **INSTANT REPLAY** button. This will rewind 10 seconds and play what you just watched again.



Use your Back button on your browser to return to Answers on Demand Home Page.